

**MUELLER**

MUELLER LICHTENVOORDE B.V. – Postbus 20 – 7130 AA – LICHTENVOORDE - NEDERLAND

# USERS MANUAL

# BEER TANK

# **CONTENTS**

|   | Page |
|---|------|
| CONTENTS.....                                     | 2    |
| 1. INTRODUCTION.....                              | 3    |
| 2. SAFETY.....                                    | 4    |
| 2.1 Used pictograms.....                          | 4    |
| 2.2 General safety instructions.....              | 4    |
| 2.3 Instructions for general use.....             | 4    |
| 3. PRODUCT DATA.....                              | 7    |
| 3.1. General product description.....             | 7    |
| 3.1.1 Cooling.....                                | 8    |
| 3.1.2 Inliner.....                                | 8    |
| 3.1.3 Piercing unit.....                          | 9    |
| 3.1.4 Beer distributor.....                       | 9    |
| 3.1.5 Manhole cover.....                          | 10   |
| 3.1.6 Safety pressurise fitting .....             | 10   |
| 3.2 Technical specifications.....                 | 11   |
| 4. TRANSPORTATION AND INSTALLATION.....           | 12   |
| 4.1 Placement of tank and frame .....             | 12   |
| 4.2 Installation.....                             | 13   |
| 4.2.1 Adjacent placement.....                     | 14   |
| 4.2.2 Stacked placement.....                      | 14   |
| 4.2.3 Adjustment and storage.....                 | 15   |
| 4.3 Attachment of safety fitting.....             | 15   |
| 4.4 Attachment of water-cooling system.....       | 16   |
| 4.5 Use inliners.....                             | 17   |
| 4.5.1 Opening manhole cover.....                  | 17   |
| 4.5.2 Installation / removal Mueller-inliner..... | 18   |
| 4.5.3 Installation / removal BDC-inliners.....    | 19   |
| 4.5.4 Use without inliner.....                    | 20   |
| 4.5.5 Pressurization.....                         | 21   |
| 4.5.6 Storage inliners.....                       | 21   |
| 4.6 Cleaning of the beer tank.....                | 22   |
| 4.7 Disengaging.....                              | 22   |
| 4.8 Failures and repairs.....                     | 22   |
| 4.9 Environmental aspects.....                    | 22   |
| 5. SERVICE AND GUARANTEE.....                     | 22   |
| 6. PART LIST.....                                 | 23   |
| 7. FAILURE LIST.....                              | 35   |

# 1. INTRODUCTION

This users manual (in accordance with NEN 5509) has been drawn up to help you work with and maintain the beer tank safely and sensibly.

The users manual is intended for use by the operator in charge of installation (the user). This users manual meets the requirements registered in the directions for the Pressure Equipment Directive (PED Direction 97/23/EG).

Before you start operating or carrying out maintenance, you should be familiar with the contents of this users manual. In case of any uncertainty with regard to the contents or if problems arise during the execution, please contact your deliverer or installer.

In this users manual pictograms are used, the meaning of which are described in chapter 2.

The positions in this manual (right, left, in front of, behind etc.) used to show the position of a part of the installation, are to be interpreted as seen from the operators standpoint. Unless otherwise indicated, the measurements are in metres.

For decades Mueller Lichtenvoorde BV has produced and delivered BierDrive Compatible beer tanks. Further on in this manual they will be referred to as BDC beer tanks.

Mueller Lichtenvoorde BV, hereinafter to be referred to as Mueller, has compiled this manual with the greatest care. Nevertheless, we cannot completely exclude the possibility of error. Mueller does not assume any responsibility for mistakes and subsequent damages.

## 2.0 SAFETY

### 2.1 USED PICTOGRAMS

The following pictograms are used in this manual:



#### TIP

Gives the user suggestions and advice on how to carry out certain procedures more easily and effectively.



#### ATTENTION

Alerts the user to possible problems.



#### CAREFUL

Warns the user for possible damage to the machine or the product if the procedures are not executed correctly.



#### WARNING

Warns of (serious) bodily injuries if the procedures are not executed correctly.

### 2.2 GENERAL SAFETY INSTRUCTIONS

Secure all dangerous areas wherever possible. Nevertheless, great caution is required both during the use and the inspection and maintenance of the beer tank.

No responsibility whatsoever can be accepted in the event damages or bodily injuries resulting from failure to observe the indications in this users manual or by neglect during use, adjustment or maintenance of the installation.

To minimize any chance to injury while working on or with the beer tank it is necessary to protect oneself by means of safety shoes, safety glasses, hearing protection and working gloves etc.

### 2.3 INSTRUCTIONS FOR GENERAL USE

The correct operation of the pressure vessel is an essential condition for safe usage. To this end the following considerations are to be observed by the user:

1. All of the procedures in the following description of maintenance work or other work on the pressure vessel should be performed only by qualified personnel.
2. The pressure vessel may only be used for its designed purpose with the intended operating media indicated and within the pressure- and temperature limits, stipulated on the nameplate and in the manual. This manual is to be kept in a safe place.

3. Operational data:

|   | Tank          | Cooling       |
|---|---------------|---------------|
| Content   | See nameplate | See nameplate |
| Max. admissible content                         | See nameplate | n.a.          |
| Max./min. admissible operating pressure         | 3 / 0 bar (o) | 3 / 0 bar (o) |
| Max./min. admissible operating temperature      | 50 / 0 °C     | 50 / 0 °C     |
| Medium  | Bier / gas    | Cooling water |
| Test pressure (at a temperature of 10 to 30 °C) | 4,3 bar (o)   | 4,3 bar (o)   |
| Weight  | See nameplate |               |

Marking of the named machine for the EG-Test according to Module B+C1: CE0044

4. The pressure vessel is designed for a predominantly inactive pressure load. As technical specification to fulfil fundamental safety requirements of the appendix I of the DRGL, Ad-2000 was chosen. The connecting coefficient is 0,85.
5. For construction units from austenitic steel, the corrosion addition is 0 mm.
6. Welding on the pressure vessel is not admissible.
7. There must be a guarantee given that, on location, the Pressure vessel will be equipped with appropriate safety- and test measures, which prevent exceeding the maximum admissible operational data.
8. The pressure vessel is to be set up in a horizontal position. The cooling water system should be filled before start-up and all air vented from system. Water should be circulated before the admission of the coat area.
9. The pressure vessel must be placed on a foundation that is designed to accommodate the weight of the full vessel.
10. Connections to the pressure vessel need to be attached strain-free.
11. During operation the pressure vessel may not be exposed to any vibrations, which can lead to fatigue failure. If necessary precautions must be taken to prevent vibrations.
12. The cooling water may not contain corrosive components, which can damage the material used. In addition, the cooling water (preferably water from a closed cooling circulation system) must be free of rough contamination or other impurities, which may cause clogging in the cooling jacket of the pressure vessel. If necessary a filter can be connected.
13. During maintenance and/or inspection of the pressure vessel, the welds must be cleaned and checked for damages. New seals (original parts) are to be used. The safety valve must be checked for correct operation. Before beginning maintenance and/or inspection work, make sure that the vessel is no longer under pressure, completely emptied. During maintenance and/or inspection, operation may not be initiated by a third party. When maintenance and/or inspection work has been completed, a pressure test must be done before the vessel can resume operation.
14. The national regulations regarding the industrial safety, valid at the place of assembly, are to be observed.


15. The national regulations valid at the place of assembly, regarding the operation of pressure machinery are to be observed.
16. The pressure vessel may only be lifted empty. A suitable lifting device should be used for lifting.
17. During filling the operating instruction of the operator are to be followed up. The valid national regulations regarding the industrial safety are to be observed.
18. When emptying the vessel make sure that no vacuum develops.

## 3.0 PRODUCT DATA

### 3.1 GENERAL PRODUCT DESCRIPTION

Ever since 1982 Mueller developed, produced and delivered beer tank systems. These tank systems can be described as follows (see picture 3.1):

1. Cooling
2. Inliner (see picture 3.2)
3. Plug-in unit
4. Distributor
5. Manhole cover
6. Safety pressurise fitting



Picture 3.1



Picture 3.2


### 3.1.1 COOLING

The beer tanks that are delivered are either single walled and without insulation or double walled and insulated.

The double-walled system is provided with a cooling spiral or cooling plates. The advantages of this system are the possibility of placing the tanks anywhere with minimal alterations to the surroundings. The tanks must not be exposed to frost or full sunlight (for connection options see pictures 3.3 & 3.4).



Picture 3.3



Picture 3.4

Single walled beer tanks are usually kept in cool cells. The advantage of this system is that the entire system is cooled and the installation of the beer tanks is easier (size and weight). The main disadvantage is the room it takes up in the cool cell.

### 3.1.2 INLINER

An inliner, also called a beer liner is a bag (see picture 3.5) made of plastic (low pressure polyethylene with food approval), which is filled with beer so that when empty, the bag can be removed thus making the cleaning of the tank basically unnecessary. In using an inliner, special discharge openings are applied, the so-called plug-in units.



Picture 3.5



### 3.1.3 PIERCING UNIT

The piercing unit is applied with the use of an inliner and serves as a pressure- and fluid-tight seal between the tank and the beer discharge openings. The plug-in unit is available according to the Mueller (see picture 3.6) and BDC (see picture 3.7) principle. The fundamental difference between both systems is the way the inliner is locked (see installation of the Mueller inliner, Chapter 4.5.2 & Installation / removal of the BDC inliners, Chapter 4.5.3).

With the Mueller construction, the inliner can simply be pushed into the appropriate bush. By installing the piercing unit the inliner will then be sealed hermetically for beer and air or CO<sub>2</sub>.

With the BDC construction, the inliner has to be pushed out from the inside through the appropriate bush and then the inliner has to be secured from the outside to the spout of the inliner by means of two moon shells. By installing the piercing unit the inliner will then be sealed hermetically for beer and air or CO<sub>2</sub>.



Picture 3.6



Picture 3.7

### 3.1.4 BEER DISTRIBUTOR

The Mueller distributors are available in the constructions 1x, (see picture 3.8) 2x, 4x and 6x (see picture 3.9). All constructions are built to a universal scale except for 1 distributor (see parts list). Clearly this means that only the distributor plates are different. Every seal, clamp, etc. is identical.

The distributors are provided with a non-return valve. This enables removal of the beer hose from the one tank and mounting it to the other without spillage. Furthermore it prevents beer flowing back from the beer hose into the beer tank, thus guaranteeing the quality of the beer in the tank.

In addition, the distributor can be dismantled completely for cleaning and maintenance without any tools.



Picture 3.8



Picture 3.9

### 3.1.5 MANHOLE COVER

The beer tank can be opened by means of an oval manhole cover, which can be removed or swung inwards (named a hinged manhole cover). For further use of the manhole cover see chapter 4.5.1.


### 3.1.6 SAFETY PRESSURISE FITTING

With an application of a working pressure of 3 bar, Mueller beer tanks have to be provided with a CE approved excess pressure safety category IV. We advise installing the standard Mueller safety pressure fitting. The safety pressure fitting must be inspected regularly to make sure it is operating correctly.

Picture 3.10 shows the components of the safety pressurise fitting.



***If the fitting falls and / or is damaged, it must be replaced immediately.***



**Picture 3.10**

## 3.2 TECHNICAL SPECIFICATIONS

Technical specification of the beer tank:

| <b>Table 3.1 – Data pressure vessel / accessory</b> |                              |
|---|------------------------------|
| Contents pressure vessel (range)                    | 250, 500, 1000 of 1600 litre |
| Contents accessory                                  | 0,05 – 0,3 litre             |
| Max. admissible pressure                            | 3 bar(o)                     |
| Max. / min. admissible temperature                  | 50 / 0 °C                    |

| <b>Table 3.2 - PED (97/23/EG) data</b> |  |
|--|--|
| Contents pressure vessel (acc. art.9)  | Liquid – group 2 (beer)<br>gas - group 2 (CO2 / air) |
| Contents accessory                     | Liquid - group 2                                     |
| Category according PED, appendix 2     | Category III   |
| Module according PED, appendix 3       | B+C1   |

| <b>Table 3.3 – Other technical data</b>               |                                |
|---|--------------------------------|
| Material tank   | 1.4301 (AISI 304)              |
| Material outside housing                              | 1.4301 (AISI 304)              |
| Wall thickness cylinder                               | 2 mm                           |
| Wall thickness bottoms                                | 2,1 mm                         |
| Wall thickness outside housing<br>(by isolated tanks) | 1,2 mm                         |
| Connecting dimensions piercing unit                   | DN40 piercing unit             |
| Connecting dimensions distributor                     | G5/8"                          |
| Material / diameter cooling water pipe                | Copper / ½"                    |
| Length cooling water pipe / hl tank contents          | 3 m/hl                         |
| Contact surface cooling pipe                          | 0,09 m2/hl                     |
| Dimensions cooling water connection                   | 2x G5/8" of G3/4" outer thread |
| Cooling water temperature                             | Ca. 2,5°C                      |
| Cooling water delivery                                | Ca. 250 litre/hour             |
| Cooling time 10°C > 5°C                               | 20 hour                        |
| Resistance cooling spiral                             | 0,25 – 0,35 bar                |
| Dimensions manhole                                    | 420x320 mm                     |

## 4.0 TRANSPORTATION AND INSTALLATION



- *When transporting the beer tanks by truck shifting or falling of the tanks it is a risk that must be taken into account. The transporters must therefore make sure that the tanks are secured using the pallets provided by the Mueller to prevent damage occurring.*




- *Pay special attention to vulnerable protruding parts and manometers.*



- *Always inspect the beer tank for damages before transport. A damaged beer tank may not be assembled but must be given to the Mueller for inspection.*

## 4.1 PLACEMENT OF TANK AND FRAME

To use the beer tanks we advise placing them on the standard frames provided by Mueller. The 100% stainless steel frames consist of an easy-to-assemble pipe construction (see picture 4.1).



Picture 4.1

## 4.2 INSTALLATION



Because hoisting activity is necessary during assembly, the required safety precautions must be observed.



During hoisting, make sure no 'foreign' (not rust proof) metals come in contact with the beer tank as this could lead to undesired corrosion. Use of wood or plastic is advised as support material as well as use of clean slings.



Before the beer tanks can be placed, the floor destined for placement must be inspected to determine whether it can support the tank. Take point load into consideration.



In the event that the tanks are to be placed in an environment that poses potential risk (e.g. in a situation where there is the likelihood of vibrations caused by heavy traffic, earthquakes, installation on moveable platforms or on ships) consultation with the Mueller about these conditions is required so that extra stability measures can be taken in the placement of the beer tank.



Various facilities required for the beer tank. Cool water supplies, placements of a compressor, beer mains, beer hoses etc. take up space around the beer tank and can result in less space for service and waiting. At the same time, these facilities should not place any undesired reaction forces on tanks, appendages and frames as this can lead to dangerous situations (instability of the installation).




Make sure that the area in which the tank is placed has a constant temperature of between 0 and 30 °C. In other words, a frost-free area not exposed to direct sunlight.




Where CO<sub>2</sub> is used to supply pressure in the tanks is danger of suffocation exists should the CO<sub>2</sub> leak in a room where there is insufficient ventilation. MUELLER advises that where CO<sub>2</sub> is used, the national regulations concerning health and welfare be observed.

Accredited installation companies must carry out all activities undertaken to prepare for the installation of the water-cooling system, such as the placement of water mains and electricity. Once the beer tank has been checked for damage, it can be placed in the desired location. At this point only approved-of hoisting and lifting machinery must be used. Lashing gear is also admissible. It is advisable to lift the tanks from underneath, for the better distribution of pressure (see picture 4.2 & 4.3).



Picture 4.2



Picture 4.3

#### **4.2.1 ADJACENT PLACEMENT**

When placing the beer tanks in adjacent position, it is advisable to build the frames first then to place the tanks.




***All wire connections must be checked carefully with a spanner.***

#### **4.2.2 STACKED PLACEMENT**

When two frames are to be stacked, two complete and independent frames must first be built and the lower tank first, as in picture 4.4. Approximately 5 cm must be left free between the conveyor band and the insertion fitting.

Then the connection between the tubes can be made and the second frame can be placed on the first. You can then place the beer tank as illustrated in picture 4.4. The beer tank must protrude far enough out in front of the first tank that the insertion unit can be introduced. The beer tanks can also be stacked directly above each other if a raising set is used (optional).





**Picture 4.4**



*All wire connections must be checked carefully with a spanner.*

#### **4.2.3 ADJUSTMENT AND STORAGE**

After the frames for the beer tanks have been assembled, they must still be adjusted. Place the frame first level and then place the frames in a longitudinal direction on a slant with a 1 to 1.5 % angle (1 to 1.5 cm p/m) which is the lowest point that still allows flow.


#### **4.3 ATTACHMENT OF SAFETY FITTING**

The pressure/safety fitting is attached to the beer tank by means of a G3/4" wire connection. A teflon ring should be placed between the fitting and the beer tank to assure pressure tightness (see picture 4.5).



**Picture 4.5**

The connection should be secured with two spanners whereby only the rear spanner is in a fixed position (see picture 4.6). This is to prevent excess pressure to the pressure mains.



**Picture 4.6**

#### **4.4 ATTACHMENT OF WATER-COOLING SYSTEM**

The water-cooling system consists of an entry and exit opening containing a G3/4" or G5/8" threaded tube. This threaded tube connection is a solid soldered joint with a copper cooling spiral. In order to prevent damage to or stripping of the cooling spiral during removal it is necessary to secure the threaded tube (which is attached to the tank) when installing the water cooling connection with a spanner to prevent its rotation (see picture 4.7). Instead of turning the back nut key you must prevent it from turning along with the front nut key.



**Picture 4.7**



## 4.5 USE INLINERS

**ATTENTION: the inliners are designed for once-only use!!!!**

### 4.5.1 OPENING MANHOLE COVER


- Let out pressure from the beer tank through the outlet valve on the front side of the tank.
- Open the tank by opening or removing the manhole cover (see picture 4.8 & 4.9).

Hinged manhole cover



Picture 4.8

Manhole cover with clamping piece



Picture 4.9

## 4.5.2 INSTALLATION / REMOVAL MUELLER-INLINER


### INSTALLATION MUELLER INLINER:



*Replace the sealing ring under the transit bush if necessary. To do so remove the coupling nut DN32 at the bottom of the tank and then push the bush up / inside. Be careful not to lose the peg on the transit bush (picture 4.10)!*



Picture 4.10



Picture 4.11

- Clean the transit bush and the piercing unit as described in the cleaning instructions (H 4.6).
- Replace the transit bush in its former position.
- Remove the new inliner from the packaging; check it for possible damages and install the inliner in the beer tank (see picture 4.11).



Picture 4.12



Picture 4.13

- Push the Mueller inliner with the connection into the outlet bush (see picture 4.12) of the beer tank. Check if the Mueller inliner is lying straight in the beer tank (picture 4.13).



*Attention: the inliner has been rolled up (in the packaging) in such a way that, after the installation of the inliner in the beer tank, it can roll out to the back and then unfold to the side when it is filled (see picture 4.13).*

- Replace the piercing unit in its old position (see picture 4.14).
- Tighten the coupling nut with the special hook spanner (see picture 4.15).




**Picture 4.14**



**Picture 4.15**

#### **REMOVAL MUELLER INLINER:**

- Close the valve of the piercing unit.
- Remove the piercing unit with the special hook spanner (see picture 4.16).
- Pull the inliner out of the tank (see picture 4.17) and clean the beer tank as described in the cleaning instructions (H. 4.6.).



**Picture 4.16**




**Picture 4.17**

#### **4.5.3 INSTALLATION / REMOVAL BDC INLINERS**

The installation of the BDC inliner is basically the same as the installation of the Mueller inliner. However, the connection has to be put through the transit bush from the inside and then the connection has to be secured with the two moon shells. Then install the rubber sealing ring (see picture 4.18 & 4.19).






**Picture 4.18**



**Picture 4.19**

#### **4.5.4 USE WITHOUT INLINER**

It is possible to use the Mueller tank without inliner. To do so an additional sealing ring has to be installed (see picture 4.20).




**Picture 4.20**

#### 4.5.5 PRESSURIZATION

- Clean the manhole and the parts, which have been touched during installation, as described in 4.6 (see picture 4.21 & 4.22).




Picture 4.21



Picture 4.22

- Install the manhole cover again. The hand-twining wheel should not be tightened completely otherwise the cover will not serve as implosion security.
- Bring the beer tank to a pressure of 1 bar (see picture 4.23).



Picture 4.23

#### **CHECK AIRLEAKAGE INLINER:**

- Open the valve of the piercing unit, so the air, which is in the inliner can escape.
- Close the valve again and wait for approx. 15 seconds before opening the valve of the piercing unit again. There should be no longer any air escaping. If there is still air escaping the inliner is leaking or the sealing at the outlet bush is insufficient. Replace the inliner by repeating the above mentioned steps if necessary.
- If there is no more air leakage, the tank can be filled with beer.



***Take care that the first approx. 100 litres are pumped into the tank steadily.***

#### 4.5.6 STORAGE INLINER

- Don't store inliners in the sunlight;
- Don't store inliners next to aroma substances or similar substances;
- Store inliners in a dry place;
- Store inliners in a dark place;
- Store inliners between 4°C and 20°C.

#### 4.6 CLEANING OF THE BEER TANK

- Use only soap and water to clean the beer tank.
- Because the beer tank serves for storage of beer, it has to be cleaned regularly.
- In case of spilling and leakage of beer, clean these surfaces directly with water and soap.



***Never use chloride containing cleaning agents or solvents!***

#### 4.7 DISENGAGING

- Tap the beer.
- Remove all pressure from the system.
- Tap all liquids.
- Clean the whole installation.



**With double walled tanks: when storing outdoors empty the cooling spiral totally to avoid the danger of frost.**

#### 4.8 FAILURES AND REPAIRS

- See chapter .7: Failures and repairs.

#### 4.9 ENVIRONMENTAL ASPECTS

If the installation must be disassembled and disposed of, this can be done by reversing the order of assembly as set out in the instruction manual.

The parts of the beer tank do not constitute any danger to the environment.

#### 5.0 SERVICE AND GUARANTEE

- In accordance with the Metaalunie Voorwaarden (Metaalunie Conditions).


## 6.0 PART LIST

### CONTENTS:

- 6.1 MUELLER PIERCING UNIT 90°
- 6.2 TRANSIT BUSH FOR MUELLER PIERCING UNIT 90°
- 6.3 BDC PIERCING UNIT 90°
- 6.4 BDC PIERCING UNIT STRAIGHT
- 6.5 BDC PIERCING UNIT 90° WELD / WELD
- 6.6 SAFETY FITTING
- 6.7 SIGHT GLASS DN50
- 6.8 SIGHT GLASS DN80
- 6.9 MANHOLE COVER
- 6.10 CO2 DISTRIBUTOR
- 6.11 BEER DISTRIBUTOR (1-LINE)
- 6.12 BEER DISTRIBUTOR (2-/4-/6- LINES)
- 6.13 FRAME BEERTANK DOUBLE WALLED (D=860 mm)
- 6.14 FRAME BEERTANK SINGLE WALLED (D=790 mm)
- 6.15 FRAME BEERTANK DOUBLE WALLED (D=700 mm)
- 6.16 FRAME BEERTANK SINGLE WALLED (D=630 mm)


## 6.1 MUELLER PIERCING UNIT 90°

|                |                                  |
|----------------|----------------------------------|
| <b>803 821</b> | <b>Mueller piercing unit 90°</b> |
| 807 017        | O-ring                           |
| 807 282        | O-ring                           |



## 6.2 TRANSIT BUSH FOR MUELLER PIERCING UNIT 90°


|         |   |
|---------|---|
|         | <b>Transit bush for<br/>Mueller piercing unit<br/>90°</b> |
| 236 622 | Pin   |
| 236 623 | Threaded bush   |
| 236 621 | O-ring  |
| 803 494 | Cap nut   |






### 6.3 BDC PIERCING UNIT 90°

|                  |                              |
|------------------|------------------------------|
| <b>3475 0141</b> | <b>BDC piercing unit 90°</b> |
| 36 037           | O-ring                       |
| 807 335          | O-ring                       |
| 807 337          | O-ring                       |
| 808 563          | Filling disks                |




### 6.4 BDC PIERCING UNIT STRAIGHT

|                  |                                   |
|------------------|-----------------------------------|
| <b>3475 0142</b> | <b>BDC piercing unit straight</b> |
| 36 037           | O-ring                            |
| 807 335          | O-ring                            |
| 807 337          | O-ring                            |
| 808 563          | Filling disks                     |




## 6.5 BDC PIERCING UNIT 90° WELD / WELD

| 3475 0144 | BDC piercing unit |
|-----------|-------------------|
| 807 335   | O-ring            |
| 807 337   | O-ring            |
| 808 563   | Filling disks     |




## 6.6 SAFETY PRESSURISE FITTING

| 804 043 | Safety pressurise fitting |
|---------|---------------------------|
| 807 021 | Manometer                 |
| 807 023 | Safety valve              |
| 807 044 | Winged nut                |
| 807 047 | Hose attachment           |
| 807 279 | Sealing ring              |
| 807 359 | Holder lip valve          |
| 807 360 | Lip valve                 |
| 807 392 | Ball valve                |
| 808 633 | Casing non-return valve   |
| 808 634 | Rubber sealing ring       |




## 6.7 SIGHT GLASS DN50

| Sightglass DN50 |                    |
|-----------------|--------------------|
| 803 990         | Swivel sight glass |
| 803 991         | Sight glass        |
| 807 697         | O-ring             |
| 807 698         | Sealing disk       |




## 6.8 SIGHT GLASS DN80

| Sightglass DN80 |                    |
|-----------------|--------------------|
| 803 501         | Swivel sight glass |
| 803 870         | Sight glass        |
| 807 683         | Sealing ring       |
| 807 684         | Sealing ring       |




## 6.9 MANHOLE COVER

|                  |                      |
|------------------|----------------------|
| <b>3475 0553</b> | <b>Manhole cover</b> |
| 803 438          | Sealing ring         |
| 803 474          | Spring               |
| 803 475          | Handwheel            |
| 803 504          | Sealing lid          |
| 135 494          | Sealing ring         |
| 34710019         | Clamp                |
| 34730016         | Manhole lid          |




## 6.10 CO2 CONNECTION

|                |                        |
|----------------|------------------------|
| <b>803 988</b> | <b>CO2 distributor</b> |
|----------------|------------------------|



## 6.11 BEER DISTRIBUTOR (1 LINE)


| 3475 0566 | Beer distributor (1-line) |
|-----------|---------------------------|
| 807 856   | O-ring                    |
| 807 857   | O-ring                    |
| 807 858   | Spring                    |
| 36 039    | Swivel nut                |
| 807 933   | Clamp casing              |
| 807 934   | Non-return valve          |
| 3473 0297 | Casing                    |





## 6.12 BEER DISTRIBUTOR (2-/ 4- /6- LINES)

|                  |                                   |
|------------------|-----------------------------------|
| <b>3475 0120</b> | <b>Beer distributor (2 lines)</b> |
| <b>3475 0121</b> | <b>Beer distributor (4 lines)</b> |
| <b>3475 0122</b> | <b>Beer distributor (6 lines)</b> |
| 807 919          | Non-return valve                  |
| 808 540          | Clamping ring                     |
| 808 541          | Sealing ring                      |
| 808 542          | O-ring                            |
| 808 555          | Spring                            |
| 3473 0250        | Casing                            |
| 3473 0251        | Distributor plate (2-lines)       |
| 3473 0252        | Distributor plate (4-lines)       |
| 3473 0253        | Distributor plate (6-lines)       |




### 6.13 FRAME BEER TANK DOUBLE WALLED (D=860 mm)


500 litre: 3475 0057

1000 litre: 3475 0052

1600 litre: 3475 0126




**Lateral girders:**




# 6.14 FRAME BEER TANK SINGLE WALLED (D=790 mm)

500 litre: 3475 0077

1000 litre: 3475 0075



## Lateral girders:







### 6.15 FRAME BEER TANK DOUBLE WALLED (D=700 mm)

250 litre: 3475 0113

500 litre: 3475 0105




Lateral girders:




# 6.16 FRAME BEER TANK SINGLE WALLED (D=630 mm)

250 litre: 3475 0088

500 litre: 3475 0090



## Lateral girders:



## 7.0 FAILURE LIST

| Complaint                                     | Cause  | Immediate cause                               | Solution  |
|---|--|---|---|
| Tank does not pressurize / pressure decreases | Manhole cover is leaking                       | Sealing ring broken                           | Replace ring  |
|   |  | Hand-twining wheel not tightened              | Inspect the position of the clamping bar and tighten the hand-twining wheel |
|   | Piercing unit                                  | Coupling nut not tightened                    | Fix the coupling nut with a hook spanner                                    |
|   | Pressure outlet valve                          | Outlet valve not closed                       | Close outlet valve  |
|   | CO2 fitting is leaking                         | Plastic sealing ring is broken                | Replace plastic sealing ring  |
|   | Sight glass is leaking                         | Sealing ring is broken                        | Replace sealing ring  |
|   | Safety pressurize fitting dropping too quickly | Safety pressurise valve is broken             | Replace safety pressurise fitting   |
| Safety pressurize valve not well adjusted     |  | Turn out/screw in the safety pressurize valve |   |
| Refrigeration is not running                  | No supply of refrigerant                       | Valves are still closed                       | Open valves   |
|   |  | Pump is not running                           | Turn on pump  |
| No or too little pressure on the tap pipe     | CO2 inlet not correct                          | Pressure too low                              | Increase pressure   |
|   |  | Compressor is not running                     | Turn on Compressor  |
| Beer leakage at piercing unit                 | Piercing unit not well connected               | Sealing ring is broken                        | Replace sealing ring  |
|   |  | Moon shells forgotten                         | Install moon shells   |
|   | Inliner not well connected                     | Outlet Inliner damaged                        | Replace Inliner   |